

Product Features

- RF frequency: 3 to 16 GHz
- Linear Gain: 16 dB
- OIP3: 29 dBm
- PKG Size: X=7 mm, Y=7mm, Z=0.8 mm
- DC Power: 5 VDC, 250 mA

Product Description

Application

- Instrumentation
- 5G Wireless
- SATCOM
- Military Radar, EW

The TMC161 ADC interface low noise quasi differential amplifier consists of a differential anti-alias filter, a pair of quasi differential distributed low noise amplifiers and designed to be integrated with a balun packaged in an air-cavity QFN. TMC161 is designed for use in 5G wireless, SATCOM, Instrumentation and Military Radar and EW applications. The TMC161 is a 50 Ω matched design with built-in bias-T which eliminates the need for RF port matching and external bias-T. To ensure rugged and reliable operation and moisture protection, the TMC161 is designed and layed out for maximum reliability. Both bond pad and backside metallization are Au-based that is compatible with ribbon and wedge bonding and high conductivity epoxy and eutectic die attach methods. The anti-alias filter can be custom designed to reject clock frequency and its mixing components.

Electrical Performance : Vdd = 5 V, Vgg = -0.7 V, TA = 25 °C							
	min	Тур	Max	Units			
Frequency	3		16	GHz			
Gain		16		dB			
Noise Figure		6		dB			
OIP3		29		dBm			
Return Loss		10		dB			
Bias Voltage		5		V			
Bias Current		250		mA			

mmTron Inc. reserves the right to make changes to the product(s) or information contained herein without notice. Version 3.1 2024 For additional information and application support please visit: https://www.mmTron.com/contact



Bias Sequencing: To turn ON the device, VG1, and VG2 are first set at -1V. Then set VD1 and VD2 to 5V. Finally, adjust VG1 and VG2 to achieve ID1=ID2=125mA. To turn OFF the device, you set VG1 and VG2 to -1V, then turn off the VD1 and VD2 followed by turning off VG1 and VG2.

Pad #	Function	Pad #	Function	Pad #	Function
2	Input Detector Voltage	9	VDD BIAS (Input bar)	22	GND
3	Input	11	VGG BIAS (Input bar)	28	VCAD BIAS (Input)
4	GND	13	VCAD BIAS (Input bar)	30	VGG BIAS (Input)
5	Input bar	20	GND	32	VDD BIAS (Input)
6	Input bar Detector Voltage	21	Output		

mmTron Inc. reserves the right to make changes to the product(s) or information contained herein without notice. Version 3.1 2024 For additional information and application support please visit: <u>https://www.mmTron.com/contact</u>

mmTRON

ing the Frontier

Unlea





Input and output signals are DC coupled (need to add blocking capacitors)



mmTron Inc. reserves the right to make changes to the product(s) or information contained herein without notice. Version 3.1 2024 For additional information and application support please visit: <u>https://www.mmTron.com/contact</u>



mmTron Inc. reserves the right to make changes to the product(s) or information contained herein without notice. Version 3.1 2024 For additional information and application support please visit: https://www.mmTron.com/contact

mmTRON

rontier

Unleashing the mmWave Fronti





mmTron Inc. reserves the right to make changes to the product(s) or information contained herein without notice. Version 3.1 2024



- Recommended Biasing
 - The TMC161 is operated with one positive supply VDD (VD1=VD2) and one negative supply voltage VGG (VG1=VG2). The positive supply must be connected to VD1 and VD2 pads on the package. The negative voltage VGG should be connected to VG1 and VG2 pads on the package. The VGG is biased to -1V first, then VDD is gradually biased to +5V and finally, VG1 and Vg2 are adjusted to around -0.7V for ID1=ID2=125mA DC current.
 - Reverse the sequence during power down, i.e. bring the VGG to -1V, lower VDD to 0V, and then VGG to 0.
- Assembly Techniques
 - The TMC161 is fabricated using a GaAs-based semiconductor material structure and is to be packaged in an air-cavity QFN. The package is back-metalized and can be mounted with standard PCB assembly techniques. The mounting surface should be clean and flat.
- ESD Warning
 - III-V MMICs are ESD-sensitive. Preventative ESD measures must be employed in all aspects of storage, handling, and assembly. MMIC ESD precautions, handling considerations, and die-attach and bonding methods are critical factors in successful III-V MMIC performance and reliability.
- RoHS Compliance
 - This part is RoHS compliant, meeting the requirements of the EU Restriction of Hazardous Substances Directive 2002/95/EC, commonly known as RoHS. Six substances are regulated: lead, mercury, cadmium, chromium VI (hexavalent chromium), polybrominated biphenyls (PBB), and polybrominated biphenyl ethers (PBDE). RoHS compliance requires that any residual concentration of these substances is below the Directive's maximum concentration values (MCV): cadmium 100ppm by weight and all others 1000ppm by weight.





Pad #	Function	Pad #	Function	Pad #	Function
2	NC	9	VDD BIAS (Output bar)	22	GND
3	Output	11	VGG BIAS (Output bar)	28	VCAD BIAS (Output)
4	GND	13	VCAD BIAS (Output bar)	30	VGG BIAS (Output)
5	Output bar	20	GND	32	VDD BIAS (Output)
6	NC	21	Input		

Leave pins 13 and 28 are internally biased. Leave them open for normal operation. They can be biased externally for fine-tuning the performance.

Input and outputs are DC coupled. DC blocking caps are needed, Choose values to adjust the low-frequency end.

Connect all other pins to GND.



mmTron Inc. ("mmTron"). All rights reserved.

The information contained in this this datasheet is for reference only. All specifications are subject to change without prior notice.

Except as provided in its Terms and Conditions of Sale or any separate agreement, mmTron assumes no liability or responsibility whatsoever, including for (i) errors or omissions in these materials; (ii) failure to update these materials; or (iii) conflicts or incompatibilities arising from future changes to specifications and product descriptions, which mmTron may make at any time, without notice. These materials grant no license, express or implied, to any intellectual property rights. THESE MATERIALS ARE PROVIDED "AS IS" WITH NO WARRANTY OR LIABILITY, EXPRESS OR IMPLIED, RELATING TO SALE AND/OR USE OF mmTron PRODUCTS INCLUDING FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, INFRINGEMENT OF INTELLECTUAL PROPERTY RIGHT, ACCURACY OR COMPLETENESS, OR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM USE OF THESE MATERIALS. mmTron products are not intended for use in medical, lifesaving or life sustaining applications. mmTron customers using or selling mmTron products for use in such applications do so at their own risk and agree to fully indemnify mmTron for any damages resulting from such improper use or sale. These items are controlled by the U.S. Government and authorized for export only to the country of ultimate destination for use by the ultimate consignee or end-user(s) herein identified. They may not be resold, transferred, or otherwise disposed of, to any other country or to any person other than the authorized ultimate consignee or end-user(s), either in their original form or after being incorporated into other items, without first obtaining approval from the U.S. government or as otherwise authorized by U.S. law and regulations'.

The product layout, and specification are mmTron Proprietary and confidential information. The recipient agrees not to copy, alter, modify, reverse engineer, or attempt to derive the composition or underlying information, structure or ideas of any Confidential Information and must not remove, overprint, deface or change any notice of confidentiality, copyright, trademark, logo, legend or other notices of ownership from any originals or copies of mmTron's information.